


**"Optional Item"
Wire Snow Clip**


**Installation
for
Strato Barrier**

The purpose of the wire snow clip is to automatically release the Cat Fence-In netting from the brackets whenever too much wet snow accumulates on the netting. This will prevent damage and reduce the job of bending the brackets back into shape by hand.



1. TOOLS: pliers, screwdriver, and scissors.

2. With pliers, grasp the clip at the eye or rounded section. At the bracket eye on the front section of the bracket, insert the wire clip from the bottom into the bracket eye.



3. Add a short twist tie to the eye of the clip. Bring netting up and attach it with the short twist tie.

4. Use pliers to adjust for more tension. Use a screw driver to separate the clip for less tension.


**"Optional Item"
Wire Snow Clip**

**Installation for
Combination Barrier**

The purpose of the wire snow clip is to automatically release the Cat Fence-In netting from the brackets and rods whenever too much wet snow accumulates on the netting. This will prevent damage and reduce the job of bending the brackets back into shape by hand.

1. TOOLS: pliers, screwdriver, and scissors.

2. At the top of the adjustable "S" rod: With pliers, grasp the snow clip at the eye or rounded section. Going from under, insert the clip at the bottom section of the "S."



3. At the bracket end: With pliers, grasp the snow clip at the eye or rounded section. Going from under, place the clip in back of the bolt at the bracket eye. Insert the wire clip from the bottom into the bracket eye.

4. Add short twist ties to the eyes of the clips. Bring the netting up and attach it with the twist ties.

5. Use pliers to adjust for more tension. Use a screw driver to separate the clip for less tension.

